



HANSA

Installation and maintenance guide



4-9



10-11




12-19



20-22



22-25






26-29



30

4416 0210




I (ISO 3822)
 EN1112
 50 - 500 kPa
 0.20 l/s (300 kPa w/Controller)
 max. +65°C



mpi.hansa.com/44160210

4416 0210 0009




I (ISO 3822)
 EN1112
 100 - 1000 kPa
 0.15 l/s (300 kPa w/Controller)
 max. +65°C



mpi.hansa.com/441602100009

4415 0330

I (ISO 3822)
 EN1112
 50 - 500 kPa
 0.20 l/s (300 kPa w/Controller)
 max. +65°C



mpi.hansa.com/44150330



A  5x40 x 2

B  21/3x3 x 2

C  8x40 x 2

D  4x12 x 2



1

1

4416 0210

4415 0330


4416 0210 0009

4415 0330 0009


1



L




L = max 720











L = max 915

4413 0200








L = max 915





①



cleaning.hansa.com